



Balise Group Identification		Identificarea Grupului de Balize	
<p>First European of BG A doua Europeană de BG</p> <p>0-bcd-e → "Nominal Direction" of BG</p> <p>0 → BG Function:            C: Conexiune Radio            A: Nivelul de Tranzitie Anuntat (L0&gt;L2)            D: Disconectare RBC            P: Schimbare faza            R: Recolibrare            Li: Nivelul de Tranzitie (Sistemul de Semnalizare Traditional &gt; ERTMS)            SR: Stop # in "Start" Responsabil Mode</p> <p>bcd → ID-Station: BRS(Brasov)-SR(Supin)-BPO(Bod)-FD(Feldioara)-PR(Apuzes)-RCS(Rescu)-CTA(Cala)-RCH(Rachio)-VNT(Vandani)-LSB(Libesti)-SGL(Sighisoara)</p> <p>e → Referred Object            BG type R, SR: next signal            BG type F: Change Phase axis in KM, side X of Y, nominal or reverse direction</p>	<p>First European de BG A doua Europeană de BG</p> <p>0-bcd-e → "Directia Nominala" of BG</p> <p>0 → Functia BG :            C: Conexiune Radio            A: Nivelul de Tranzitie Anuntat (L0&gt;L2)            D: Disconectare RBC            P: Schimbarea fazei            R: Recolibrare            Li: Nivelul de Tranzitie (Sistemul de Semnalizare Traditional &gt; ERTMS)            SR: stop deza in Modul "Start" responsabil</p> <p>bcd → ID-Station: BRS(Brasov)-SR(Supin)-BPO(Bod)-FD(Feldioara)-PR(Apuzes)-RCS(Rescu)-CTA(Cala)-RCH(Rachio)-VNT(Vandani)-LSB(Libesti)-SGL(Sighisoara)</p> <p>e → Object de Referinta            BG tip R, SR: semnal urmator            BG tip F: Schimbarea fazei axei in KM, partea X a lui Y, directie inversa sau nominala</p>		
SYMBOLS		SIMBOLURI	
<p>balise group</p> <p>END OF AUTHORITY (EaA) - "End Station Name Acronym" - "v" Refered Signal</p> <p>EOA with RELEASE SPEED - "End Station Name Acronym" - "v" Refered Signal</p> <p>JOINT</p> <p>TRACTION POWER - Change Phase Post</p>	<p>GRUP DE BALIZE</p> <p>SPRANSUTUL AUTORIZATII (EaA) - "End Station Name Acronym" - "v" Semnal de Referinta</p> <p>EOA cu RELEASE SPEED - "End Station Name Acronym" - "v" Semnal de Referinta</p> <p>IMBINAURE</p> <p>PUTERE DE TRAGTINE - Schimbarea fazei de post</p>		
<p>Slope</p> <p>PION</p> <p>ENTRY</p> <p>CURVE</p> <p>EXIT</p>	<p>PONTO</p> <p>INTRARE</p> <p>CURBA</p> <p>IESIRE</p>		
<p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p>	<p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p> <p>Right</p> <p>Left</p>		
<p>NOTE: These symbols → show train direction</p>	<p>NOTA: Aceste simboluri → indica directia trenului</p>		